



To Adjust the brakes on the kiterisers for the models not listed on the compatibility sheet:

1- adjust the brake line so that the line is tight and the trailing edge start to be pull down when the «Tbar» of the handle reaches the bottom pulley.

To start with, try to set up the stopperball 120 to 150mm shorter than the original brake line lenght.

2- make sure that when the «Tbar» is at the level of the clip, the brake line is loose and the trailing edge not pull down.

Warning:

If the brake lines are set to short, the risk is getting a very unstable wing when you start to put your hands up!

We don't recommend to use Kiterisers on LittleCloud gliders before 2014 and sizes below 16m2!

Always set up the limiter to 150mm to start.

Any questions: info@littlecloud.fr